

- Remove the side cover with its mesh by pressing against the pump nozzle.
- Insert a thin screwdriver into the small indentation next to the rotor; this allows you to pull the rotor out.
- If there are oil residues, briefly immerse all parts in rubbing alcohol or clean each part by using rubbing alcohol and a small brush.
- In the event of limescale residues, clean all parts by briefly immersing them in water and vinegar essence or in 1 tbsp of citric acid.
- After cleaning, please reinsert the rotor. The rotor must now toggle back and forth in the rotation direction when it is manually given a slight push. If this does not happen, the internal pin within the pump and the pin guide in the rotor must be cleaned again. Finally, assemble all pump parts completely and conduct a test run in the water.

### Safety instructions for the use of essential oils and fragrance blends

Please carefully read the enclosed user manual and the information on the label of the essential oils and fragrance blends you are using. Do not use viscous or strong or intensely pigmented essential oils, as they may damage the device. You can find more information on this in our online shop or at the PRIMAVERA customer service or Online [www.primaveralife.com/duftbrunnen-rondo.html](http://www.primaveralife.com/duftbrunnen-rondo.html).

### Disposal

If this electronic device is no longer used, all consumers are legally obliged to dispose of it separately from unsorted household waste. Electric devices are, therefore, marked with the symbol shown below. You can deposit devices at the collection point of the public waste management authorities or at disposal points set up by the manufacturers and retailers in line with the German Electrical and Electronic Equipment Act (Elekt - roG). You can find an online directory of collection and disposal points in Germany at [www.ear-systems.de](http://www.ear-systems.de). These collection points are regulated according to 2012/19/EU, subject to state and legislation.



Manufacturer of the fountain pump:  
Oase Italia S.r.l.  
Via S. Antonio, 22  
36056 TEZZE SUL BRENTA (VI)

### Disclaimer


We exclude any liability for damage caused by improper use or damage caused by the use of essential oils.

PRIMAVERA LIFE GMBH  
Naturparadies 1  
87466 Oy-Mittelberg  
Germany  
[www.primaveralife.com](http://www.primaveralife.com)



PRIMAVERA®

# Aroma Fountain



**Important Information  
About Usage and Cleaning**

## Dear Customer,

Many thanks for choosing the PRIMAVERA Rondo Aroma Fountain.

To enjoy this high-quality aroma fountain as long as possible, we ask you to please read the enclosed instructions carefully and pay close attention to all the safety advice.

We wish you a lot of joy and many fragrant hours with your new Aroma Fountain.

Fragrant greetings from the Allgäu.  
Your PRIMAVERA Team

## Aroma fountains

- create a soothing air humidification
- refresh and purify the atmosphere
- increase your personal well-being
- are an enrichment and eye-catcher for any living space
- the soft splashing sound has a harmonizing effect on the body, mind and soul

## Scope of delivery

- Ceramic water bowl, glazed inside and out
- Ceramic source sphere, glazed on the outside
- Submersible water pump
- Connecting hose
- Instruction manual for fountain and pump

## Important information

Before operating the aroma fountain, please carefully read the operating instructions for the aroma fountain and the pump. Keep both instructions in a safe place. In particular the safety instructions for the pump are to be observed exactly.

The aroma fountain should be emptied and cleaned daily after use. Please allow all parts to dry completely before operating the fountain again.

## Operating instructions

- Fill three quarters of the fountain bowl with water. It is best to use filtered, distilled or low lime content water. This protects the fountain and the pump.
- Please make sure to set up the fountain on a non-slip, tilt-resistant and waterproof surface.
- Please keep out of reach of children and disoriented persons.
- Do not leave the aroma fountain unattended while in operation!
- Insert the connecting hose through the upper outlet of the top part of the fountain until both edges close evenly. To do this, moisten the connecting hose with some water.

- Then insert the fountain pump nozzle into the connecting hose from below.
- By rotating the pump nozzle you can regulate the effervescence of the fountain.
- Proceed to center the upper part of the fountain along with the pump on top of the bowl. The connecting hose should not protrude from the source sphere opening at the top.
- Only then insert the power plug of the pump into the socket (230 volts). If you encounter startup problems, please unplug the device and add some water from above, through the source sphere. Then insert the power plug into the socket again.
- Please make sure to never insert or remove the power plug from the outlet with wet hands!
- Now you can add your desired essential oil blend into the bowl or onto the source sphere of the fountain. Please use no more than 5 -10 drops of a 100% pure and natural essential oil blend, depending on the desired intensity.

## More notes and tips

- The pump's performance and the associated effervescence can be regulated by rotating the pump nozzle.
- Please refill with water regularly so that the entire pump is submerged in water.
- Clean your fountain regularly, at least weekly and when you do, fill it with fresh water.
- Always disconnect the power plug from the socket when cleaning the fountain.
- The pump is designed for continuous operation.

## Thorough care and maintenance of your aroma fountain is important. Diligent care is worthwhile!

We recommend cleaning your fountain regularly. This way you will be able to enjoy it for a long time.

The frequency of complete cleaning depends on:

- the lime content of your water
- the essential oil blends used

Please perform a complete cleaning every week!

Before you begin cleaning, always disconnect the power plug from the socket! Then start by rinsing the individual parts with a mild dishwashing liquid.

Fill with fresh, warm water at about 68 degrees F/20 degrees Celcius adding a generous shot of vinegar essence or 1 tbsp of citric acid and let the fountain run for several hours. Once the cleaning cycle is completed, the pump and the fountain must be rinsed thoroughly. **Then leave all the parts to dry completely.**

If you desire to change the fragrance it is recommended to perform a complete cleaning beforehand.

Cleaning of the pump in case of heavy limescale or contamination.

- Disconnect the power plug from the socket.
- Remove the pump and pull off connecting hose.
- Pre-clean all parts with a mild dishwashing liquid.